



Rotating Remote Controlled TV Antenna

Product Manual




Package Contents


NO.	NAME	Qty.	Image
1	Main Unit	1	
2	Main Pole Column	1	
3	Motor-Fixed Bolster	1	
4	U-Frequency Post	1	
5	U-Frequency Vibrator	5	
6	Screw(3x10mm)	5	k)mm⊳
7	Screw(4x12mm)	9	Quum>
8	Power Supply	1	
9	Remote Controller	1	
10	75 ff Coaxial Cable	1	
11	Power Adapter	1	
12	Coaxial Cable Gasket	1	
13	Instruction	1	
14	Optional support rod accessories	1	withit a




P4: Connect Signal Line





P5: Secure Antenna




P1: Install U-Frequency Vibrators









P2: Open Reflection Panel




Open the Reflection Panel as shown.

P3: Install Motor Rotor









C:Place the Motor-Fixed Bolster onto the Main Unit D:Insert the four 4x12mm screws to secure. as shown.