



Electric skateboards
USER GUIDE



www.anzoskate.com
support@anzoskate.com


Skateboard illustrations and instructions



| | | | |
|----------------|---------------|---------------------|---------|
| Specification | 700*220*140mm | Climb angle | 25% |
| Net weight | 3.65kg | Maximum loadbearing | 100kg |
| Plate material | 7 PLY Maple | Motor | 300w |
| Endurance | 6-8KM | Battery performance | 2200MAH |
| Maximum speed | 15km/h | Wheel size | PU72MM |

※Maximum Range and hill climb depends on road condition, terrain and temperature.

Battery Charging Instructions



Recharge time: 2.5 hours (0%→100%)

Charging Method: Connect the AC end of the standard charger to the 100-240VAC socket. Insert the DC into the charging port. When the charger indicator turns red, it indicates that the connection is normal and the battery is being charged. When the charger indicator turns green, it indicates that the battery is fully charged.

The first time you use a skateboard, please fully charge the skateboard and use it. Please turn off the power when you are finished skateboarding. Even if you don't use a battery, you should charge it at least once a month.

Remote control instructions



Switching direction:

Long press the reverse key to switch the sliding direction, the connect light show green means the positive direction; The connect light show red means opposite direction.

Connect the skateboard and the remote control:

Turn on the remote control and the motherboard, and then press and hold the power key of the motherboard until it flashes. Then press the power key and the reverse key at the same time. When Bo on the remote control displays the power supply, it indicates that the connection is successful.

Warning

1. Please read carefully and thoroughly understand the user manual when using. It contains information that is critical to your security.
2. We are not responsible for any damage or injury caused by unsafe use or malfunction. Unauthorized repairs or modifications are the responsibility of the user.
3. Only available to persons aged 16 and over.
4. Knee pads, elbow box wrist protective equipment and certified safety helmets should be worn at all times when sliding.
5. It is forbidden to use it on motorized lanes or roads that are not allowed. It can only be used on flat roads such as asphalt and cement or on gentle slopes. Pay special attention to the brakes when going downhill.
6. It is forbidden to do any stunts and dangerous actions on the electric scooter.